

## Cirro 2 Manual



### **How to fill the clearomiser:**

Unscrew the black mouth piece which is used to draw upon. Inject the e-liquid by squeezing the bottle making sure that the liquid DOES NOT go down the central tube. Once the process is complete replace the black cap. Allowing the e-liquid to soak in for 3-5 minutes helps protect the atomiser and ensures that you get a great vape from the start. DO NOT disassemble the clearomiser as this is not required and may cause damage. The clearomiser is a disposable part and will need replacing every 1 - 2 weeks depending upon individual use. Additional clearomisers are available from our website [www.10motives.com](http://www.10motives.com).

### **Battery:**

The expected lifespan of the battery is approximately 6 months. All batteries come with a 3 month warranty from the date of purchase. Should any fault occur with the battery within this period please do not hesitate to contact our customer service department. A full charge should last approximately 8 hours. The habits of the user will determine the actual time the battery will last.

### **Using the Cirro Vapouriser:**

On first use the battery will be locked. To unlock suppress the LED button 5 times within 2 seconds. The LED indicator will then flash BLUE 3 times. It is very important that this step is done quickly enough; otherwise the battery will not turn on. To use the Cirro battery the button needs to be suppressed when having a draw. The LED indicator will then light up BLUE. If you would like to lock the battery yourself repeat the process for unlocking and press the button 5 times within 2 seconds. If left for a certain amount of time without any use the battery will automatically lock itself.

### **How to charge:**

Connect the USB charger to a power source. This can be a computer/laptop, TV USB port or one of our chargers. We ONLY recommend using one of these methods to charge the Cirro battery. The clearomiser needs to be separated from the battery. The battery then can be connected to the USB charger. Once connected the LED indicator will light up RED. The charging time required is 2.5 – 3 hours and we recommend that battery is left for this length of time before being disconnected. Once fully charged the LED indicator will light up GREEN.